


DILLON

EDxtreme Dynamometer and Crane Scale



Optional
Communicator



User Instructions

© Avery Weigh-Tronix, LLC 2012 All rights reserved.

No part of this publication may be reproduced, stored in an electronic retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise without the prior written consent of the copyright owner, or as permitted by law or under license. Full acknowledgment of the source must be given. Avery Weigh-Tronix is a registered trade mark of the Avery Weigh-Tronix, LLC. This publication was correct at the time of going to print however, Avery Weigh-Tronix, LLC reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service at any time.

All third party brands and product names used within this document are trademarks or registered trademarks of their respective holders.

Table of Contents

	<i>page</i>
Chapter 1 General information and warnings	5
About this manual	5
Text conventions	5
Special messages	5
Safe Operation	6
Safe handling of equipment with batteries	7
Routine maintenance	7
Cleaning the machine	7
Training	7
Sharp objects	8
FCC and EMC declarations of compliance	8
Modifications	8
Radio Safety	8
Radio Communications Reliability	8
Chapter 2 Introduction	10
EDX Front Panel	10
EDX Keys	11
EDxtreme Connector	11
Communicator Front Panel	12
Communicator Keys	13
Communicator Connectors	13
Power On and Annunciators	14
Chapter 3 EDX Operation	16
Display Modes	16
Force Measurement	16
Force Measurement Rezero	17
Displaying Peak Force	17
Chapter 4 EDX Setup	18
Setup Menu	18
Setup--Ptfmt	18
Setup--Misc	20
Setup--About	21
Setup--Test	21
Chapter 5 Configuration	23
Configuration Menu	24
Config--Setup	24
Config--Reso	24
Config--Comm	25
Config--Mode	28
Config--Units	28
Config--Power	29
Config--ChPwd	30
Config--Reset	30
Chapter 6 Communicator Operation	31
Powerup Display	31
Communicator Setup Menu	32
Communicator Config Menu	34

Communicator Print Formats	35
Chapter 7 General Information	37
Changing Batteries	37
Battery Life	37
Care	37
Radio Information	38
Installing Spacers	38
Chapter 8 Common Configurations	40
Chapter 9 Troubleshooting	42
Chapter 10 Weighing and Force Measurement Practices	44
Load Centering	44
Alignment	44
Proper Pin Fit	44
Torque and Bending	44
Certified Gear	44
Good Force Measurement Practice	45
Chapter 11 Specifications	46
Dynamometer Specifications	46
Communicator Specifications	47
Radio Specifications	47

1 General information and warnings

1.1 About this manual

This manual is divided into chapters by the chapter number and the large text at the top of a page. Subsections are labeled as shown by the 1 and 1.1 headings shown above. The names of the chapter and the next subsection level appear at the top of alternating pages of the manual to remind you of where you are in the manual. The manual name and page numbers appear at the bottom of the pages.

1.1.1 Text conventions

Key names are shown in **bold** and reflect the case of the key being described. This applies to hard keys and onscreen or soft keys.

Displayed messages appear in ***bold italic*** type and reflect the case of the displayed message.

1.1.2 Special messages

Examples of special messages you will see in this manual are defined below. The signal words have specific meanings to alert you to additional information or the relative level of hazard.



WARNING!

This is a Warning symbol.

Warnings mean that failure to follow specific practices and procedures may have major consequences such as injury or death.



CAUTION!

This is a Caution symbol.

Cautions give information about procedures that, if not observed, could result in damage to equipment or corruption to and loss of data.



NOTE: *This is a Note symbol. Notes give additional and important information, hints and tips that help you to use your product.*

1.2 Safe Operation



WARNING: If you overload this dynamometer you could suffer severe injuries or death. The total load on the dynamometer should NEVER exceed the rated capacity.

Keep all the following in mind as you use the EDX dynamometer.

The system capacity is equal to the rating of the dynamometers. The shackle rating should not be used to determine lift capacity of the system.

The shackles are rated in metric tons. Thus the 12-ton shackles are rated to 26,450 lbf and are suitable for use on the 25,000 lbf dynamometer.

Any zeroed deadload must be considered as part of the ultimate load.

Although this instrument has a substantial overload protection rating, the instrument should not be used above the rated capacity. Doing so can significantly impact fatigue life of the instrument and cause premature and abrupt failure. If a higher capacity reading is needed, Dillon insists that a larger instrument be used.

Safety is always a concern in overhead lifting and tensioning applications. To limit your liability always insist upon factory supplied shackles and pins and factory tested and certified safe optional equipment. All DILLON products are designed to meet the published Safe Working Load (SWL) and Ultimate Safety Factor (USF) standards of the United States Military.

Do not grind, stamp, drill or deform the metal on the dynamometer body in any way. Protect the instrument from impact in use and storage.

Any significant damage or deformation to the loading element is cause for evaluation by Dillon, particularly in the element side members to the right and left of the display.

Relieve all torsional and off axis loads.



CAUTION: Remove batteries from instrument when using the external AC power supply.

Apply load in the center of the shackle bow with this instrument.

Off center loading results in substandard performance.

Instrument requires time to stabilize when changing temperatures.

Use only the hardware supplied with this instrument. If no hardware was supplied, insure that the mating pin and shackle bow is equivalent to the hardware used at calibration. Otherwise substandard performance or failure can result.

Dillon recommends only using qualified rigging hardware and cannot be responsible for unapproved hardware.

This instrument is not designed for the following:

- Applications that see rapid, dramatic temperature swings or thermal shock. Wide variation in readings can occur.

- Environments with high electromagnetic fields such as cranes employing electromagnets to lift metal. These induce trace voltages that are picked up within the load cell lead wiring and appear as inaccurate loads.
- Intrinsically safe environments. This unit has not been Factory Mutual tested.

1.2.1 Safe handling of equipment with batteries



CAUTION: *Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.*

ATTENTION: *Il y a danger d'explosion s'il y a remplacement incorrect de la batterie, remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.*

1.3 Routine maintenance



IMPORTANT: *This equipment must be routinely checked for proper operation and calibration. Application and usage will determine the frequency of calibration required for safe operation.*

1.4 Cleaning the machine

Table 1.1 Cleaning DOs and DON'Ts



DO	DO NOT
Wipe down the outside of standard products with a clean cloth, moistened with water and a small amount of mild detergent	Attempt to clean the inside of the machine
Spray the cloth when using a proprietary cleaning fluid	Use harsh abrasives, solvents, scouring cleaners or alkaline cleaning solutions
	Spray any liquid directly on to the display windows

1.5 Training

Do not attempt to operate or complete any procedure on a machine unless you have received the appropriate training or read the instruction books.

To avoid the risk of RSI (Repetitive Strain Injury), place the machine on a surface which is ergonomically satisfactory to the user. Take frequent breaks during prolonged usage.

1.6 Sharp objects

Do not use sharp objects such as screwdrivers or long fingernails to operate the keys.

1.7 FCC and EMC declarations of compliance

1.7.1 Modifications

The FCC states that any changes or modifications to this device that are not expressly approved by Dillon may void the user's authority to operate the equipment.

1.7.2 Radio Safety

The radiated output power of this device is far below the FCC radio frequency exposure limits. Nevertheless, the device shall be used in such manner that the potential for human contact during normal operation is minimized.

When connecting an external antenna to the device, the antenna shall be placed in such a manner to minimize the potential for human contact during normal operation. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 3 inch (7.5 cm) during normal operation. The antenna is located at the connector panel on the Communicator.

1.7.3 Radio Communications Reliability

Radio systems are vulnerable to interference, resulting in delays between the dynamometer scale and remote. In some instances of interference, the display shown on the remote may be several seconds old. This can result in a hazardous situation when the system is used as the reference for acceptable loads in cases such as proof loading and monitoring of binding or overload. In these applications where timely updates are critical, a communication cable should be used to physically connect the EDxtreme and Communicator remote (see setup of RS-485 communications). Alternately, the EDxtreme display can be observed directly.



WARNING: Low power radio systems should not be used in applications where timely updates of readings are required for safety purposes.

United States

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Canada

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la Classe A prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

European Countries

WARNING: This is a Class A product. In a domestic environment, this product may cause radio interference in which the user may be required to take adequate measures.

Agency Identification Numbers	
US/FCC	CAN/IC
KQL-PKLR2400	CAN2268391158A

2 Introduction



WARNING: *If you overload this dynamometer you could suffer severe injuries or death. The total load on the dynamometer should NEVER exceed the rated capacity.*

The EDxtreme™ (EDX) electronic dynamometer from Dillon is a force measurement load sensor and digital readout in one instrument. The EDX can be used to measure tension or weight. It can operate stand-alone or be coupled with a remote Dillon Communicator, via radio communication or direct wire connection, for improved convenience, functionality and safety.

This manual covers the setup and operation of the EDX and optional Communicator. General information is covered in the right column of each page with major sections separated by the black bar shown above. Subheads appear in the left column along with any special notes, cautions or warnings.

This manual covers the following:

- EDX & Communicator Description
- EDX Setup, Configuration and Operation
- Communicator Setup
- General Information on the EDX
- Troubleshooting

Be sure to read the safety precautions found in *Safe Operation* on [page 6](#).

2.1 EDX Front Panel

The EDX comes in several weight capacities. All have the same front panel, shown in [Figure 2.1](#).



Figure 2.1 EDxtreme front panel

2.1.1 EDX Keys

There are four “hard” keys and four “soft” keys. The hard keys are permanently labeled and the soft keys are just below the display. The soft key functions change and the key label appears above each key on the display. Sometimes the individual soft keys are referred to as the F1, F2, F3 and F4 keys as numbered from left to right.



On/Off key Use this key to turn the unit on and off.



ZERO key Use this key to zero the force indicated on the display.



ESC key Use this key to escape from portions of the menu structure and return to previous choices or displays.



Arrow key Use this key to access any available soft keys not currently viewed.

2.1.2 EDxtreme Connector

The connector on the EDxtreme is recessed for protection. It is used to connect the instrument to a Communicator remote display/controller, printer or external power supply. See your Dillon distributor for details.

2.1.3 Communicator Front Panel

Figure 2.2 shows the Dillon Communicator. This is a battery powered, radio-linked (or wired) remote display and control unit.












Figure 2.2 Dillon Communicator

2.1.4 Communicator Keys

The Communicator has the same keys as the EDX but also some extra ones. They are all explained below:

	On/Off key	Use this key to turn the unit on and off. Also, when in Radio Mode, this key will access a menu for further options.
	ZERO key	Use this key to zero the force indicated on the EDX and Communicator displays.
	ESC key	Use this key to escape from portions of the menu structure and return to previous choices or displays.
	Arrow key	Use this key to access any available soft keys not currently viewed.
	Up and Down key	Use these arrow keys to move through menu choices, when applicable. Also scrolls through any active links.
	Remote Setup key	Use this key to access the Setup menu.
	Display Mode key	Use this key to cycle between Communicator display modes. They are EDX specific force value, EDX specific peak value, multiple display of force values and multiple display of peak values.
	Keypad keys	Use these keys to enter numeric characters. Use for address assignments and other miscellaneous data entry.

2.1.5 Communicator Connectors

The Communicator may have between 2-3 connectors. CELL is for wireline communications with an EDxtreme. COM1 is for serial communications. AUX is not presently used and is either nonfunctional or not installed.

2.2 Power On and Annunciators

When you power up the EDX you will see a display similar to the example shown on the left in [Figure 2.3](#).




Figure 2.3 Initial displays




Depending on permission settings and/or revision of firmware, various soft keys may be in a different location or not visible.

The display sample above shows several symbols you may see on your display but usually not all at the same time.

- Force.** This tells you that the display is showing live force measurement at the moment. Will show Peak when viewing Peak Mode.
- lbf** Current unit of measure is lbf in this example. May also be kgf, N, or up to 2 other custom units.
- ~** Motion symbol. This appears when the force is in motion. This symbol disappears when motion ceases.
- Y** This shows the radio is configured ON but is not in communications with any Communicator.
- Y** The battery in the device is low and the radio section has been turned off. The device will continue to display (EDX will display force applied and Communicator will display dashes) but will be unable to communicate by radio or, EDX or the Communicator are improperly configured for RF communications on Comm port #2 with no RF PC board installed.
- (Y) (Y)** 2 Ys indicate the Communicator is in communication with an active EDX.
- Battery icon** Battery annunciator. This shows approximate remaining battery life.
- P** Capture of a new peak value. This annunciator will remain lit for a few seconds.



lbf and kgf are units of force, not weight. See Config--Units [on page 28](#) for more information.

Press the **Arrow** key,  , to move between the two displays in Figure 2.3. In the display on the right in Figure 3, one of the soft keys is labeled Setup. Press this and you gain access to the soft keys shown in the Setup Menu in Figure 4.

3 EDX Operation

3.1 Display Modes

The EDX has several display modes accessible by pressing the **Mode** soft key. See Figure 3.1.

The first display mode when you power up is the live force measurement mode.

Press the **Mode** soft key and the display changes to peak measurement mode. This mode shows the peak force applied to the EDX since the last peak clearing action. Delete the peak reading by pressing the **Clear** soft key.



Power up display modes may be configured. See Config>Mode section.

Press the Mode soft key again and the display shows live force and peak readings simultaneously.

Press the Mode soft key again and the display returns to the force measurement mode.

3.2 Force Measurement

Follow these steps to perform a gross force measurement.

1. Turn on the unit with the **On/Off** key.
2. Remove any weight from the EDX.
3. Zero the EDX by pressing the **ZERO** key.
4. Apply the force to the EDX and read the gross force on the display.

You can change the units of measure of the display by pressing the Units soft key. See the note below. Zero reference is maintained after instrument power off and will be recalled with the next power-on. Zero reference may be lost if battery power is removed.



Unit of measure can be changed only if multiple units are enabled in the Configuration menu.

3.3 Force Measurement Rezero

Rezeroing allows the weight or load of fixturing to be invisible to the measurement. The zeroed load must always be considered as part of the maximum capacity.

1. Turn on the unit with the **On/Off** key.
2. Remove any weight from the EDX.
3. Zero the EDX by pressing the **ZERO** key.
4. Apply the tare force to the EDX and press the **ZERO** key.
5. Apply the force to the EDX and read the net force on the display.

Steps 2 and 3 are not required if the weight of the fixturing is not needed. This should be maintained, however, to know cumulative loads.

3.4 Displaying Peak Force

The EDX will store the peak force applied until that reading is cleared. To display the peak force applied to an EDX, from the force measurement mode, press the **Mode** soft key. The display changes to display menu #2 shown in Figure 3.1 which is the peak display mode. The peak force is displayed. You can clear this by pressing the Clear soft key.

Peak reading is maintained after instrument power off and will be recalled with the next power-on. Peak reading may be lost if battery power is removed.




Figure 3.1 Display mode menu

Press the **Mode** soft key repeatedly until the desired display mode is reached.

4 EDX Setup

To begin using the EDX, it is recommended that you set it up to suit your specific needs and equipment. You can access the SETUP menu with the soft keys. See *Common Configurations* on page 40 to view some common configurations.




Figure 4.1 Operator setup menu for the EDxtreme



See Figure 10 for communicator setup and corresponding flow diagram.

4.1 Setup Menu

Press the appropriate soft key shown in Figure 4.1 to accomplish the functions listed on the following pages.

4.1.1 Setup--Ptfmt

Press the **Ptfmt** soft key to select the print format that will be sent to a peripheral printer when you press the **Print** soft key. Choose from the formats below. Data sent is shown below. The default is format #1.

Format #1 Current displayed value (peak or live force) plus unit of measure

104.5 lbf (live force example)

302.5 lbf (peak force example)

104.5 lbf (dual mode example)

302.5 lbf

Format #2 Live force value plus unit of measure on 1st line
Peak force and unit of measure on 2nd line

104.5 lbf

302.5 lbf

Format #3 Live force value plus unit of measure on 1st line
Peak force and unit of measure on 2nd line

Descriptive prefixes on each line

Force 104.5 lbf

Peak 302.5 lbf

Format #4 Fixed position output. Works well with RS-232 utilities, such as WedgeLink, for parsing into a spreadsheet such as Microsoft Excel. (comma separated)

Excel	A	B
1	104.5	lbf
2	302.5	lbf

Fixed characters.

Position	Description
1-8	Live force number
10-16	Displayed unit of measure (up to 7 characters)
18-25	Peak force number
27-33	Displayed unit of measure (up to 7 characters)
9,17,26	Commas
34	Carriage return

Example 1

```
<sp><sp><sp>104.5,<sp><sp><sp><sp>lbf, <sp><sp><sp>302.5,<sp><sp><sp><sp>lbf<CR>
```

Example 2 (custom unit)

```
<sp>140000.,<sp><sp><sp><sp><sp>kg,<sp>165450., ,<sp><sp><sp><sp><sp>kg<CR>
```

This would yield (shown in courier):

```

1111111111122222222222333333333334444444444455555555
123456789012345678901234567890123456789012345678901234567
104.5,      lbf,      302.5,      lbf, <CR>
140000.,      kg, 165450.,      kg, <CR>
```

Format #5 Live force, unit of measure, peak force, unit of measure. All tab separated.

104.5<tab>lbf<CR> (if presently displaying live readings)

302.5<tab>lbf<CR> (if presently displaying peak readings)

104.5<tab>lbf<tab>302.5<tab>lbf<CR> (if presently displaying dual mode)

4.1.2 Setup--Misc

Press the **Misc** key to access the following soft key set (refer to Figure 4):

- Flash** Press this soft key to enable or disable the “display flash” feedback. If enabled, the press of a key causes the display to momentarily flash to give you a visual feedback that the key was activated.
- Zero** Press this soft key enable or disable if a press of the **Zero** key also clears the Peak force value. If you enable this function, press the **Zero** key to clear the Peak force and zero the load. If you disable the function, the **Zero** key will only zero the load. Peak force remains in effect and will only be cleared with the Clear function during operation.
- Contr** Press this key to adjust the contrast of the LCD display. Press the **Up** soft key to lighten the contrast. Press the **Down** soft key to darken the contrast.
- There is a keypad shortcut for increasing and decreasing contrast. While in normal display mode press **Arrow** key and **F2** simultaneously to increase contrast. Press **Arrow** key and **F1** simultaneously to decrease contrast.



Sometimes the individual soft keys are referred to as the F1, F2, F3 and F4 keys as numbered from left to right.

- Blite** If the optional backlight is installed, press this key to adjust the backlight brightness and sleep timer functions. Press the **Inten** soft key to set the background brightness. Press the Mode soft key to set the backlight configuration options. There is a keypad shortcut for increasing and decreasing backlight intensity.

Press **Arrow** key and **F4** simultaneously to increase intensity. Press **Arrow** key and **F3** simultaneously to decrease intensity.



Use of the backlight will affect battery life.

4.1.3 Setup--About

The next soft key is the About. The About menu shows an assortment of information about your Dillon instrument. This can be handy for maintaining calibration, troubleshooting or determining if the firmware can be upgraded. Press this and access the following soft key set (refer to Figure 4):

Device Press this to see software revision and dynamometer information.



Dillon suggests that calibration data be recorded and saved.

Calib This soft key access the following soft key set:

Points Press this key to display the calibration loading points. This is useful information that can be keyed in manually in the event instrument memory is ever accidentally overwritten or corrupted.

Print Press this key to transmit all the calibration information available to a serial printer or computer.

O.Load Lists the number of overloads that have occurred since the last calibration.

Zero Lists the current zero point compared to the calibration zero point. If the zero point has moved significantly, this may indicate a serious overload has occurred and the instrument should be returned for service.

Ntwrk Lists radio information; the enabled channel and identifier.

4.1.4 Setup--Test

The Test functions can help service technicians remotely diagnose your Dillon instrument by showing information on key internal functions. Typically these menus will have significance only to trained technicians. You may look at these menus without technical guidance, but the information may have little meaning, or an error may be reported that may not exist.

Press this key to access the items described below (refer to Figure 4.1):

Batt Press this key to perform a battery test. This shows the battery level in A-D counts and approximate voltage. Voltage is not calibrated.

A-D Press this key to test the A-D section of the EDX. You need to apply force to change the counts and test the unit. The A-D is the electronics portion that converts analog load cell signal to digital numbers.

Disp. Press this key to perform a display test. Stop the test by pressing the ESC key.

Keys Press this key to perform key tests. Any key pressed will be reflected in the display. Press ESC to end the test.

Ntwrk Press this key to perform a self-test of the radio's system.

Comm The serial test is an internally conducted diagnostic which requires a jumper across transmit and receive. This requires a plug or cable assembly. Press the following soft key:

COM2 Press this key to test COM2 in a loopback test.



*To perform a COMM test, the unit **must be configured to use RS-232 communications**. It does not work in RS-485.*

5 Configuration

The configuration menu is a group of settings that may be password protected if desired to prevent operators from making significant system changes. It is used to configure the following:

- radio network
- resolution
- communication ports
- power up display mode
- units of measure
- power management
- password management
- system default reset

To access the configuration menu, press the Config soft key shown in Figure 5.1.




Figure 5.1 Accessing Config soft key and menu

The display prompts for a password. See Figure 5.2.




Figure 5.2 Password screen

Use the **Num** keys to enter the first character of the password and the **Adv** key to move to the next character. When you are done press the **Enter** key and the soft keys shown in Figure 5.3 become available.



The default password is "0". If the password has been changed and forgotten, contact your Dillon distributor for assistance.

5.1 Configuration Menu




Figure 5.3 Configuration menu

5.1.1 Config--Setup

The first soft key is **Setup**. Press this and you access the setup menu shown in Figure 4.1. All its features are covered in that section of the manual.

5.1.2 Config--Reso

Reso stands for resolution. Resolution is the value by which the EDX displays increments. Press this key to set the unit to standard (1000 divisions) resolution or enhanced (5000 divisions) resolution. For example: 10,000 lbf would count by

10 lbf (10,000 lbf/1000 divisions = 10 lbf) in standard resolution

2 lbf (10,000 lbf/5000 divisions = 2 lbf) in enhanced resolution


Standard resolution may have 1000 or 1250 divisions. Enhanced resolution may have 4000 or 5000 divisions. This follows normal display increment practice of changing by 1, 2, 5 or a multiple or submultiple of those numbers (e.g. 10, 20, 50, .1, .2, .5, etc.)

5.1.3 Config--Comm

Press the **Comm** key to enable or disable radio communication and configure serial ports.

To configure serial ports, follow these steps:

1. Press the **Comm** key and you see the following screen:




RS-232/RS-485 activity consumes more battery power.

COM2 is used to configure the optional radio board, if installed.

2. Press **COM 2** or **COM 1**.

The following display appears.



3. Select a transmission level using the **Sel** keys to scroll through the four choices; Disabled (default), RS232, RS485, and RF. RF stands for Radio Frequency and means transmission would be by radio (requires optional radio board). Press **Enter** to accept the setting. See note below.



If you set the Trans Level to RF, steps 3-5 are automatically set and do not appear.

The following display appears:

Baud: (*57600)		
Sel ↑	Sel ↓	Enter



*The * indicates which option is currently selected.*

The standard 4-pin connector only has one serial connection (COM 2).

4. Select a baud rate using the **Sel** keys to scroll through your choices. Choices are 1200, 2400, 4800, 9600, 19200, 38400, 57600 (default), and 115200. Press **Enter** to accept the setting.

The following display appears:

Parity: (*None)		
Sel ↑	Sel ↓	Enter

5. Select a parity value using the **Sel** keys to scroll through your choices. Choices are none (default), odd and even. Press **Enter** to accept the setting.

The following display appears:

Databits: (*8)		
Sel ↑	Sel ↓	Enter



Default Serial Communications

Baud Rate = 57600
Parity = None
Databits = 8
Stop bits = 1

There is no option for handshakes. All settings should be None.

6. Select a databit value using the **Sel** keys to toggle between the two choices; 7 or 8 (default). Press **Enter** to accept the setting.

The following display appears.

Mode: (Continuous)		
Sel ↑	Sel ↓	Enter

7. Select a mode of communication you want using the **Sel** keys to scroll through these choices; **Continuous**, **Poll**, **Remote** and **Print Key Only**. Press **Enter** to accept the setting.

If you choose **Continuous**, you will be prompted to select a print format for the transmission and a rate at which you want to send the transmission.

If you choose **Poll** you will be prompted to enter a poll character. Enter the ASCII value of the poll character.

Choose **Remote** for wireline communications to the Communicator and Trans Level (*RS485)

Choose **Print Key Only** to print only when the **Print** key is pressed.

8. Press **ESC** to return to the first soft key set of the Configuration menu.

If you enable the radio:


- You are asked to enter a Radio Channel. Your EDX and Communicator must be on the same channel to function together. Key in a number from 1 through 64. 1 is the default setting. Press **Enter** to accept.
- You are asked to enter a Network ID#. This is a unique address number (1-15) so the Communicator only speaks to one instrument at a time without “cross-talking.” Use the available soft keys to enter a number (1-15), then press **Enter** to accept.
- You are then asked to key in an alternate network identifier. Use the available soft keys to enter alpha characters, then press **Enter** to accept.

5.1.4 Config--Mode

The next menu key is the **Mode** key. Use this key to choose what display mode is active upon powerup.

1. Press the Mode key.

The following is displayed:



2. Select a display mode value using the **Sel** key to scroll through the choices. Press **Enter** to accept the displayed setting.

The display returns to the first soft key set of the Configuration menu.

5.1.5 Config--Units

The next soft key is **Units**. Use this item to set the units of measure you want available when you use the Units key in the normal operating mode. This can also assign custom units.

Custom units are typically used for any of three purposes:

1. To display a unit of measure not found in the standard options, such as ton, tonne, dyne, or KIP.
2. To apply a multiplier when multipart line systems or other static line arrangements are used. For example, if a 4-part line is used, the dynamometer at the dead end can display approximate total weight by using a multiplier of 4.

It is critical that the operator understands the relationship between the dynamometer and custom unit. For example, assume a custom unit of kg is entered where 1 kg = 5 kgf (as seen at the dynamometer). The operator could become confused, think that a 1000 kg display means that there is still 4000 kg of capacity remaining.

3. To compensate for local gravitational differences. There are variances in gravity throughout the world. If used as a scale, variances due to gravitational differences can be handled by having the instrument calibrated on-site with certified dead weights or by using the custom units. Simply divide the gravitational constant at your location by 9.80665 m/ss (or 32.1741 ft/s²) and use this as the multiplier entry. A less accurate alternative: If the constant is not known, lift a weight of known mass close to the capacity of the instrument. In enhanced resolution mode, observe the reading. Divide the actual by the observed reading and use this as the multiplier entry.

5.1.6 Config--Power

The next soft key is the **Power** key. Use this to set power management features.

1. Press the Power key.

The following is displayed:

Enable Auto-Shutdown? (Yes)			
No	Yes		Enter



Powering the instrument off regularly allows the batteries to partially recover and maximizes energy extractions from the batteries.

Auto-Shutdown powers off the instrument automatically. The instrument can be programmed for a fixed operating time or programmed to shut down after a period of inactivity.

Standby Timer(min): 10_			
Num↑	Num↓	Adv→	Enter

Timer reflects the period required to pass before Auto-Shutdown activates.



Key presses reset the timer. Characters received through the serial port also reset the timer.

The following screen is displayed:

Motion Resets Timer? (Yes)			
No	Yes		Enter

Select **Yes** if you only want the instrument to automatically shut down when there is inactivity. Select **No** if you want the instrument to power down after the timer counts down, regardless of any activity.

5.1.7 Config--ChPwd

The next soft key is **ChPwd**. Use this to change the password used to access the configuration menu.

IMPORTANT: Changing the password denies access to this menu without entry of the new password. Contact your Dillon distributor if you lose your password.

5.1.8 Config--Reset

The last soft key in this set is the **Reset** soft key. Use this to reset the system to its factory default settings.

This concludes the Configuration menu section.



6 Communicator Operation

The Dillon Communicator is a remote display and control module designed to work with the EDxtreme. It can be connected by wire or can communicate by radio if both the Communicator and EDxtreme are equipped with optional radio boards.

The Communicator may simultaneously view and control 15 dynamometers at one time. Each is monitored individually by assigning unique numeric identifiers (1-15) to each (addresses).

Several Communicators may operate in the same airspace if they are on different channels.



Use the **UP**, , and **DOWN**, , arrow keys on the Communicator to scroll through the displays of all active EDXs and a total screen.


For best performance always have different network identifiers (1-15) for EDxtremes within the same network and use different channels for systems operating anywhere close to one another.

Since most functions are identical, you should refer to the EDxtreme section for comprehensive explanation and the Communicator's section will highlight differences that exist.

The Communicator is designed to be similar in layout and function to an EDxtreme to make operation easy and intuitive. The main screen appears as it does on the EDxtreme except that the Mode soft key has been blanked. This has an actual hard key on the remote.

6.1 Powerup Display

An example of a Communicator's powerup display is shown below:



(Y)  (Y) 

The annunciators shown above appear on the Communicator display. They show battery level and radio operation for the Communicator (right side pair) and the active EDxtreme (left side pair).

There are three soft keys on the first display and four on the second display. The soft key functions are described below:

Units	Changes the displayed unit of measure. Each press advances the display through this sequence; lbf, kgf, N, custom 1, custom 2.
Print	Outputs serial data to peripheral devices attached to COM 1.
C.All	Clears the peaks on all EDXs currently in communication with the remote.
Clear	Clears the current peak value of the active EDX.
UZ.All	Resets all EDXs to calibration zero reference point.
Z.All	Zeros all EDXs currently in communication with the remote.
Setup	Accesses the Setup menu shown in Figure 6.1.
Config	Accesses the Config menu shown in Figure 6.2.

6.2 Communicator Setup Menu

The Communicator Setup menu can be accessed using the softkey or the Remote Setup hardkey.




Figure 6.1 Communicator Setup menu

Ptfmt Select from print formats 1-7. See *Communicator Print Formats* on page 35.

Ntwrk Setup the network.

First choice is Radio Channel #. Can pick 1-64. All EDXs set to this same number will communicate with this Communicator.

Next choice is number of EDXs in the network. Pick from 1-15

Next choice, you must set the address for each EDX. Each EDX in the network must have a unique number. Pick from 1-15.

Misc Lets you setup the following items:

Flash Use this to enable the visual confirmation of keystrokes. Display will flash on keystrokes if enabled.

Zero Use this to enable or disable clearing of peak force values upon **ZERO** key press or **Z.All** soft key press.

Contr Use this to adjust the contrast of the Communicator display. Follow onscreen prompts for directions.



Contrast shortcut

*There is a keypad shortcut for increasing and decreasing contrast. While in normal display mode press **Arrow** key and **F2** simultaneously to increase contrast. Press **Arrow** key and **F1** simultaneously to decrease contrast.*

Blite Use this to adjust the intensity and mode of the optional backlight. Intensity adjusts the brightness of the backlight. Using Mode you can set the backlight to OFF, ON, or TIMER. If you select TIMER, the backlight will shut off after a configurable period of time (in seconds), without a keystroke. You are also given the option of choosing if motion will reset the backlight timer to start counting again.



Backlight intensity shortcut

*Press **Arrow** key and **F4** simultaneously to increase intensity. Press **Arrow** key and **F3** simultaneously to decrease intensity.*

Test Lets you test the following items:

Batt Press this to check the battery condition. Display shows voltage condition of the batteries.

Disp Press this to perform a display test. Press any key to stop the test.

Keys Press this key to test individual key function. Press **ESC** to stop the test.

Comm Press this key to perform LOOP/NOLOOP tests on COM1. Press **ESC** to return to **Test** soft key display. COM1 must be enabled and configured to RS232 in Config menu to test.

Ntwrk Press this key to perform a radio test.

About Press this soft key to see the following information:

- Communicator Serial Number
- Firmware part number
- Revision level of software

Press **ESC** repeatedly to return to normal operation. If you have made changes you will be prompted to save the changes. Press the **Save** soft key to save the changes and return to normal operation. Press the **noSave** soft key to disregard any changes made and return to normal operation. Press the **Cancel** soft key to return to the Setup menu screen.

This completes the Setup menu description.

6.3 Communicator Config Menu

The configuration menu, shown in Figure 6.2, allows you to set the items described below. Press the **Config** soft key to enter the menu. Accept the user password displayed (default is 0) or your password if it has been customized. Press the **Enter** soft key to accept the password and access the menu.




Figure 6.2 Communicator Config(uration) menu

Comm Choose to set up the following parameters for each Comm port:

baud (default = 57600)

parity (default = none)

databits (default = 8)

mode (default = Print key only) Other choices: Continuous and Poll.

If you choose Continuous you must pick a format (see *Communicator Print Formats* on page 35) and a broadcast rate (choices are 1, 2, 5 or 10 Hz)

If you choose Poll you must choose a poll character (any ASCII character of your choosing)

Trans level:

- Com2 must be RS-485, RS-232, or RF
- Com1 can be RS-232 or disabled)

radio channel (Com2 only)

of EDXs in the network (Com2 only)

address of each EDX (Com2 only)

Mode Press this to set the display mode that will be active upon power-up.

Units Press this key to set the following:

- Choice of power-up unit of measure
- Enable or disable lbf, kgf, N, custom unit 1 and 2
- Power** Press this to set the following:
 - Enable Auto-shutdown (Y/N)
 - Shutdown Timer (set minutes before idleness causes unit to shut off)
- ChPwd** Press this to change the Config menu password.
- Reset** Press and you are given the choice of resetting the Communicator to its factory defaults.

6.4 Communicator Print Formats

Press the **Ptfmt** soft key to select the print format that will be sent from the Communicator on Com 1 to a peripheral printer when you press the **Print** soft key. Choose from the formats below. Data sent is shown below. The default is format #1.

Format #1 Current displayed value only (peak or live force) plus unit of measure on the active EDX only.

104.5 lbf (live force example)

or

302.5 lbf (peak force example)

Format #2 Live force value plus unit of measure on 1st line and Peak force and unit of measure on 2nd line for active EDX only.

104.5 lbf

302.5 lbf

Format #3 Live force value plus unit of measure on 1st line and Peak force and unit of measure on 2nd line with descriptive prefixes on each line for active EDX only.

Force 104.5 lbf

Peak 302.5 lbf

Format #4 Fixed position output for active EDX only. Works well with RS-232 utilities, such as WedgeLink, for parsing into a spreadsheet such as Microsoft Excel.

Excel	A	B
1	104.5	lbf
2	302.5	lbf

Fixed characters.

Position	Description
1-8	Live force number
10-16	Displayed unit of measure (up to 7 characters)
18-25	Peak force number
27-33	Displayed unit of measure (up to 7 characters)
9,17,26	Commas
34	Carriage Return

Example 1:

```
<sp><sp><sp>104.5,<sp><sp><sp><sp>lbf,<sp><sp><sp>302.5,<sp><sp><sp><sp>lbf<CR>
```

Example 2 (custom unit)

```
<sp>140000.,<sp><sp><sp><sp><sp>kg,<sp>165450.,,<sp><sp><sp><sp><sp>kg<CR>
```

This would yield (shown in courier):

```

111111111122222222223333333333444444444455555555
123456789012345678901234567890123456789012345678901234567
104.5,      lbf,      302.5,      lbf<CR>
140000.,    kg, 165450.,    kg<CR>
```

Format #5 Live force, unit of measure, peak force, unit of measure for active EDxtreme only. All tab separated.

104.5<tab>lbf<CR> (if presently displaying live readings)

302.5<tab>lbf<CR> (if presently displaying peak readings)

Format #6 Cell #, description, live force, unit of measure for all active EDXs plus a total.

Example:

Cell<tab>Description<tab>Live Force<tab>Units<CR>

1<tab>North<tab>104.5<tab>lbf<CR>

2<tab>South<tab>4801<tab>lbf<CR>

Total<tab><tab>4905.5<tab>lbf

Format #7 Outputs print format #6 plus peak values for all EDXs.

7 General Information

7.1 Changing Batteries

To replace discharged batteries, unscrew the battery compartment cap on the right side of the dynamometer. Remove the two C cells and replace them with the + poles inserted first. If the spring in the cap becomes detached, you can reattach it by aligning the large end over the counterbored hole and turning the spring counterclockwise while pushing the spring into the hole. The spring will work into the recess and be self-retained.

The Communicator has 4 AA batteries. To replace, remove rear battery cover and replace with fresh batteries in the proper arrangement.

7.2 Battery Life

The time required between battery changes can vary with usage, functions enabled, temperature, duration of use and recovery time, display update rate, battery grade and more.



CAUTION: Remove batteries from instrument when using the external AC power supply.

To maximize battery life:

- Disable radio if not being used. Even if an optional radio board is not installed, the software will run, if enabled.
- Disable other functions such as RS-232 and backlight.
- Warm environments result in longer battery life over cool environments.
- Use high quality alkaline batteries. **Do not use rechargeable batteries.**
- Turn off instrument when not in use. Alkaline batteries partially recover when the instrument is off.

7.3 Care

The EDxtreme is built to be rugged and endure typical industrial and commercial use. It is still, however, a precision instrument that should be treated with care. Store the instrument in its carry case with power off. Remove batteries if not being used.

7.4 Radio Information

The radio technology used in the radio equipped EDxtreme and Communicator is a 2.4 GHz digital spread spectrum system designed for communications reliability. Radio operation and the performance attained can be difficult to predict and will vary with environment and conditions. There are locations where radio use is impractical or even impossible.

Tips for best performance:

- Keep the Communicator and EDxtreme as close as possible together.
- Keep metal and other dense objects as far from the instruments as possible.
- Normally the higher that both the EDxtreme and Communicator are above the ground, the better the performance and range will be.

Many things can degrade radio signals, such as brick walls, metal reinforced concrete, machinery and even wiring within walls. Other systems such as wireless networks and cordless phones may degrade or interfere with operation of the Dillon radio-equipped system. As an FCC approved instrument on a license-free radio band, the instrument must accept interference received from other devices that share the same frequency and airspace. If other systems are colliding, it is best to isolate the device(s) that cause the interference and then take steps to eliminate the problem which may include relocation, conditional operation or retirement of the interfering device.


7.5 Installing Spacers

High capacity dynamometers with shackles of 50,000 lbf/20000kgf capacity and up, use spacers, shown in Figure 7.1, to insure proper centering of the dynamometer for performance and safety reasons.



Figure 7.1 Spacer

Do not use the dynamometer with shackles if the spacers are not installed. The EDX design incorporates an innovative method to retain these spacers, if desired, to ease shackle installation.



The finish on your parts may vary from the ones shown in these photos.

Place spacer on a solid surface and use a hammer to start the roll pins into the two small spacer holes. See Figure 7.2.



Figure 7.2 Inserting roll pin

Insert through matching holes in dynamometer body. Lay the dynamometer on the spacers on a solid surface with the roll pins protruding from the top. See Figure 7.3.




Figure 7.3 Roll pins extending above dynamometer body

Position the holes of the second spacer over the holes and tap spacer into position. See Figure 7.4.



Figure 7.4 Placing second spacer on roll pins

A punch sized slightly smaller than the holes in the spacer may be helpful. The spacers should “sandwich” the dynamometer body, but should not be drawn completely tight.

Remove the four large circular foam plugs from the carry case and it can continue to be used with the spacers attached.

8 Common Configurations

EDxtreme being used stand-alone (no RS-232 or Communicator remote)

Key Settings (EDxtreme):

- COM1 Trans Level – Disabled
- COM2 Trans Level – Disabled

EDxtreme connected to a computer

Key Settings (EDxtreme):

- COM1 Trans Level – Disabled
- COM2 Trans Level – RS-232 (all other parameters should agree with peripheral such as baud, data bits & parity)

Communicator connected to one EDxtreme by wire on CELL port

Key Settings (EDxtreme and Communicator):

- COM1 Trans Level – Disabled
- COM2 Trans Level – RS-485
- baud – 57600
- parity – none
- databits – 8
- Mode Remote (EDX only)

Communicator talking to one EDxtreme by radio

Key Settings (Communicator):

- COM1 Trans Level – Disabled or RS-232
- COM2 Trans Level – RF
- Radio Channel (1-64): 1 (this must differ from all other Communicators in the area)
- Number of EDxtremes in the Network (1-15): 1
- Address of Edxtreme 1: 1

Key Settings (EDxtreme):

- COM1 Trans Level – Disabled
- COM2 Trans Level – RF
- Radio Channel (1-64): 1 (must match Communicator channel setting)
- Network ID (1-15): 1
- Network Identifier: (enter characters or digits to identify this specific EDx) (most useful if multiple EDxs are networked to one Communicator)

Communicator talking to four EDxtremes by radio

Key Settings Communicator

- COM1 Trans Level – Disabled or RS-232
- COM2 Trans Level – RF
- Radio Channel (1-64): 1 (this must differ from all other Communicators in the area)
- Number of EDxtremes in the Network (1-15): 4
- Addresses for Edxtreme 1: 1
- Addresses for Edxtreme 2: 2
- Addresses for Edxtreme 3: 3
- Addresses for Edxtreme 4: 4

Key Settings (**EDxtreme 1**):

- COM1 Trans Level – Disabled
- COM2 Trans Level – RF
- Radio Channel (1-64): 1 (must match Communicator channel setting)
- Network ID (1-15): 1

Network Identifier: A

Key Settings (EDxtreme 2):

COM1 Trans Level – Disabled

COM2 Trans Level – RF

Radio Channel (1-64): 1 (must match Communicator channel setting)

Network ID (1-15): 2

Network Identifier: B

Key Settings (EDxtreme 3):

COM1 Trans Level – Disabled

COM2 Trans Level – RF

Radio Channel (1-64):1 (must match Communicator channel setting)

Network ID: 3

Network Identifier: C

Key Settings (EDxtreme 4):

COM1 Trans Level – Disabled

COM2 Trans Level – RF



Radio Channel (1-64):1 (must match Communicator channel setting)

Network ID: 4

Network Identifier: D

9 Troubleshooting

Problem	Possible Cause	Solution
EDX powers on momentarily and turns off	Low battery	Replace with high quality alkaline batteries. Do not use rechargeable batteries.
	Bad keypad	Have unit serviced.
EDX does not power on	Low battery	Replace with high quality alkaline batteries. Do not use rechargeable batteries.
	Bad keypad	Have unit serviced.
	Batteries installed backwards or no spring contact	Insure that positive terminals of both batteries (nub) face inward – towards the black cap. Check that spring is attached to the battery cap.
	Software reset	Remove battery cap & reinstall after one minute. Attempt to turn power on again.
Display is completely dark	Display contrast too light	Hold the Right Arrow key down while pressing the F2 key several times to increase the display contrast. If nothing occurs, release both keys. Press the power button and try again.
	Display contrast too dark	Hold the Arrow key down while pressing the F1 key several times to decrease the display contrast.
EDxtreme does not appear accurate	Check installation & system	Insure that shackles are in good working condition and aligned straight. Verify system is applying force directly through the dynamometer with no off center or torsional loads being applied to the instrument.
	Local gravitational variances	If being compared against dead-weights, check your local gravitational constant. Use custom units to compensate or calibrate on-site.
	Check repeatability	Place EDX in low-resolution mode. Lift an arbitrary weight several times as close to capacity as possible. Record each weight reading. Do the readings differ from each other? Calculate the standard deviation of the readings using a spreadsheet such as Microsoft Excel. See if the deviation is greater than 0.1% of the instrument capacity.
	Compare against a reference load.	Place EDX in low-resolution mode. Apply a known load near instrument capacity. Check calibration date.
Radio communication intermittent	Low batteries. Distance is excessive or dead-radio pocket	Bring remote closer to dynamometer. Allow several seconds to retrain.
	Excessive radio noise or interference in environment	Remove dynamometer and remote from the environment. Attempt communications in an area free of local radio signals.


Problem	Possible Cause	Solution
Radio communications not working at all	Dead batteries. Distance is excessive, dead radio pocket	Bring remote closer to dynamometer. Allow several seconds to retrain.
	Radio systems not initialized. No “Y” appears.	Enable the radio system in the COM2 configuration of both instruments (under Comm menu).
	 Displayed	Change batteries in the device when the  is blinking.
	Operating channels mismatched	Remote and link must be on the same operating channel. See EDxtreme and Communicator configurations of COM2 for radio (under Comm menu) and Common Configurations.
	Excessive radio noise or interference in environment	Remove dynamometer and Communicator from the environment. Attempt communications in an area free of local radio signals. See Radio Information section of the manual.
Remote reading changes to dashes	Low batteries, lost communications	See steps above for improving communications.
Display locks up on DILLON marquee	Poor connection between EDX and Communicator	Remove batteries from EDX and Communicator, replace them and power up.

10 Weighing and Force Measurement Practices

The basis for all electronic force measurement or weighing is measurement of stress in a loadcell body. To obtain optimal results it is necessary to establish a few basic rules, otherwise the effect may be a nonlinear or non-repeatable response. Read and follow these tips and see the illustrations on the next page.

10.1 Load Centering

For accurate performance the force acting on the unit must be in line with the unit. Centering the load is accomplished by using the shims on each side of the load cell so that it is centered on the shackle pin. See the illustration at right. The 50,000 lbf (20000 kgf) and higher EDxtremes also include spacers supplied with shackles.



10.2 Alignment

Insure shackles are oriented parallel with the instrument. Apply load in the center of the shackle bow.

10.3 Proper Pin Fit

A proper fitting pin is important in order to generate an even stress distribution and avoid yield stresses.



To achieve published accuracy you must use the shackle pins and centering spacers provided by Dillon.


10.4 Torque and Bending

Torque and bending should be avoided. Use swivels on the lifting wire for anti-torque and avoid side forces.

10.5 Certified Gear



Certified shackles and lifting gear should always be used in accordance to local laws and federal legislation. Insure all hardware, fittings and line used to sustain the load are properly sized and rated for the installation. Have the system evaluated by a qualified engineer if any question or uncertainty exists.

10.6 Good Force Measurement Practice





Be sure fixturing does not bind between the body of the EDX and the shackle!



Center the load on the shackle pin.
Use spacers to insure centering where applicable.



Use only the original factory equipment pins and shackles. Pin fit is critical and will affect accuracy.



Do not torque, bend or sideload.



Use hardware that allows single point attachment and freedom of alignment. Do not use hardware that is undersize or restricts self-alignment. This results in poor measurement performance and possible dangerous safety conditions.

11 Specifications

11.1 Dynamometer Specifications

Enclosure:	Designed to NEMA4X/IP55. Suitable for continuous outdoor use.
Accuracy:	0.1% of capacity.* 0.3% of capacity for EDX 75t and above*
Repeatability:	0.1% of capacity. 0.3% of capacity for EDX 75t and above* *1 part in 1000 display mode with Dillon provided shackles.
Factor of safety:	2.5K to 10K = 7:1 USF 25K to 100K = 5:1 USF, 220K to 330K 4:1 USF
Body Protection:	Powder painted aluminum or steel bodies.
Bearings:	Unmatched repeatability attained by needle bearings in shackle pin holes up to EDX-10K. Shackle pin acts as inner race.
Shackles:	Forged industry standard anchor shackles. Models up to EDX-10K use precision machined shackle pin. Higher capacities use forged pin.
Display:	128 x 64 dot-graphic LCD display shows up to 6 digits 1.0" (26mm) high plus annunciators and soft keys. Digits are .11 inches (3mm) thick for unmatched readability.
Display update rate:	2 times per second.
Peak capture rate:	60 times per second
Connector:	Recessed sealed connector may be used for serial communications or connection to a Communicator remote.
RS-232 / RS-485 communication:	Print or extract data easily. Continuous output can drive a scoreboard. Configurable poll character.
Calibration:	Traceable to the National Institute of Standards and Technology. Certificate included with curve of readings. Passes only with three consecutive confirming runs, with all points in specification.
Battery life:	320 hours typical use with two C-cell alkaline batteries. 40 hours typical with Radio Link system.
Operating temperature:	-4° F to 140° F (-20° to 60° C)
Included with instrument:	Carry case, batteries, manual and certificate of calibration. EDX-50K and EDX-100K with shackles include shackle crate and spacers.
Options:	Shackles, 2.4 GHz radio board, Display backlight.

11.2 Communicator Specifications

Enclosure:	Designed to NEMA 3 / IP44 with optional sleeve. Suitable for protected outdoor use.
Instrument size:	9.0 x 4.6 x 1.8 inch (228 x 117 x 45mm).
Accuracy:	Not applicable. Only sends and receives digital information.
Display:	128 x 64 dot-graphic LCD display can show full readings up to 5 instruments.
Battery life:	60 hours wireline, 20 hours radio using four AA alkaline batteries under typical use.
Operating temperature:	-4° F to 140° F (-20° to 60° C)
Connectors:	Sealed connectors may be used for serial communications and wired connection to an EDxtreme dynamometer.
RS-232 communication:	Print or extract data easily. Continuous output can drive a scoreboard. Configurable poll character.
Included with remote:	Carry case and batteries.
Accessories:	Rubberized case protector sleeve, Remote wall mount bracket, Serial and remote cable assemblies.

11.3 Radio Specifications

FCC Certified:	For unlicensed low power devices. No radio licensing or permits required for normal operation.* (In the US and Canada. Check local ordinances in other countries.)
Frequency:	2.4 GHz spread-spectrum operates between 2.402 – 2.478 GHz. Continuously and automatically changes frequencies many times per second for consistent, reliable communications.
Output Level:	10 mW (20 dBm)
Display Update Rate:	2 times per second with single dynamometer. Multi-instrument networks result in reduced updates.
Number of networks:	63 remotes can operate independently in the same airspace with unique channels.
Number of links remote can control:	Up to 15 addresses are available per network channel.
Configuration:	Address and Network channels are front-panel configurable.
Antenna:	Integral antenna.
Range:	Open-air – Up to 300 feet, line-of-sight. Indoors – Dependent upon installation site with 150 feet common.

Dillon

A division of Weigh-Tronix Inc.

1000 Armstrong Dr.

Fairmont, MN 56031 USA

Telephone: 507-238-4461

Facsimile: 507-238-8258

e-mail: dillon@weigh-tronix.com

www.dillon-force.com

DILLON

Force Measurement Products & Systems