


## Quick-Check Tension Meter Comparative Matrix



	Quick-Check "Red"	Quick-Check
<b>Markets/Industries</b>	Tower and stack guy wires, cable barriers, overhead transit wires, bridges, fall arrest, stage support, aircraft cables and public utilities	Tower and stack guy wires, cable barriers, overhead transit wires, bridges, fall arrest, stage support, aircraft cables and public utilities
<b>Capacities</b>	2000 lb or 10,000 lb 1000 kg or 4500 kg	2000 lb or 10,000 lb 1000 kg or 4500 kg
<b>Rope Calibrations</b>	Up to 20 (must be specified at time of order)	Up to 15 (must be specified at time of order)
<b>Cable Diameter Range</b>	3/16" to 1" 4.75 mm to 25.4 mm	3/16" to 1" 4.75mm to 25.4mm
<b>Display</b>	Informative Display: Shows: Unit, Wire Type, Sheave & Battery	Shows: Unit, Wire Type & Battery
<b>Date and Time</b>	Yes	No
<b>Calibration Reminder</b>	Yes	No
<b>AZT (Automatic Zero Tracking) &amp; Filtering</b>	Configurable AZT and Filtering	Fixed
<b>RS-232 Port</b>	Four pin Lemo RS-232 output	No
<b>Carry Case</b>	Yes	Optional
<b>Enclosure</b>	Suitable for continuous outdoor use	Suitable for continuous outdoor use
<b>Units of Measure</b>	Lbf, kgf and Newtons	Lbf, kgf and Newtons
<b>Temperature Range</b>	-4° F to 158° F / -20° C to 70° C	-4° F to 140° F / -20° C to 60° C
<b>Backlight</b>	Yes (configurable intensity and timer)	No
<b>Power</b>	Two AA batteries	Two AA batteries
<b>Battery Life*</b>	10Hz = over 250 hrs continuous 100Hz = over 100 hrs continuous	N/A
<b>Accuracy</b>	3% full scale	3% full scale
<b>User's Manual</b>	Yes, CD	Yes, CD
<b>Pass/Fail Tensioning Mode</b>	Yes	Yes
<b>Tower Mode</b>	Stores wire rope readings to be exported later (Stores each Leg and Wire)	No
<b>Quick-Check Calibrated to most popular Cell Tower Guy Wires</b>	Yes, now available as a new P/N, see price sheet for details	No
<b>Weight</b>	11 lb	11 lb
<b>Warranty</b>	Two years	Two years

\*Tested with backlight off **Improvements**